Issue: 12

Date: 7/1/20

Firmware: N/A



# Installation, Commissioning & Routine Gas Testing Manual

Gas Detector
Type FGD10B Infrared
Version 2
(with GSH4 Sensor)

# **Declaration of Conformity**

We declare that, on the date the equipment accompanied by this declaration is placed on the market, the equipment conforms with all technical and regulatory requirements of the directives listed below.

#### Description of Equipment:

The FGD10 Series of Infrared Fixed Gas Detectors for the detection of Carbon Dioxide or Flammable (Hydrocarbon) gases. ATEX Flameproof Certified for use in Group IIC hazardous locations.

#### Directive 2014/34/EU ATEX

The following harmonised standards were used in support of this declaration:

EN 60079-0:2018 Explosive atmospheres Part 0: Equipment - General requirements

The FGD10 was originally certified to standard EN 60079-0:2006. This standard has been compared with the above harmonised standard and no significant changes have occurred that are applicable this equipment.

EN 6079-1:2014 Explosive atmospheres Part 1: Equipment protection by flameproof enclosures 'd'.
The GGD10 was originally certified to standard EN 60079-1:2007 but is considered compliant with the above harmonised standard because both the instrument housing and GSH4 sensor housing are certified to that standard.

Notified Body for Hazardous Area Certification: CSA Group Netherlands B.V, Utrechtseweg 310, 6812 AR, Arnhem,	Notified Body for ATEX Quality Assurance Notification:  SGS Fimko Oy Särkiniementie 3 Helsinki, 00211	
Netherlands Notified Body number: 2813	Notified Body Number: 0598	
Hazardous Area Certificate Number:	ATEX Quality Assurance Notification Number:	
SIRA 08ATEX1031X (Ex) II 2 G Ex d IIC	2056	
T4 (Ta = -20°C + 60 °C ) T5 (Ta = -20°C + 50 °C ) * T5 & T6 ratings are not valid for T6 (Ta = -20°C + 35 °C ) versions fitted with an externally mounted sensor.		
Place of Manufacture:	ISO 9001:2015 Quality Management System:	

#### 2014/30/EU - Electromagnetic Compatibility

Mansfield, Nottinghamshire, UK.

Harr	non	icar	Sta	ndar	de.

EN50270:2006 Electromagnetic compatibility - Electrical apparatus for the detection and measurement of combustible gases, toxic gases or oxygen.

Certificate No. GB93/1938

Authorised Signatory to this declaration, on behalf of the manufacturer:

David Stuttard Managing Director Name: Title:

Address: Status Scientific Controls Ltd, Hermitage Lane Industrial Estate, Kings Mill Way

Mansfield, Nottinghamshire, NG18 5ER, United Kingdom

Date mark applied - see product

Date: Signature 14/10/19

Extract from TD18/100





### **CONTENTS**

1.	PAC	KAGE CONTENTS	8
2.	. SCOPE OF THE MANUAL		
3.	DESC	CRIPTION	g
	3.1.	GAS TYPES	10
4.	INST	ALLATION	11
	4.1.	CABLE ENTRIES	12
	4.2.	MOUNTING AND TERMINAL ACCESS	12
	4.3.	FGD10B CONNECTIONS	
	4.4.	WIRING DETAILS	
	4.4.1.	FGD10B Infrared	
5.	COM	MISSIONING	15
	5.1.	APPLYING POWER	15
6.	RELA	ATIVE RESPONSE CHARACTERISTICS	15
7.	INITI	AL GAS TESTING	17
	7.1.	ZERO GAS	17
	7.1. 7.2.	TEST GAS	
	7.2.1.	Gas connection points	
	7.2.1.	Sampling time	
	7.2.3.	Suggested calibration gas levels	
8.	CALI	BRATION	21
	8.1.	SENSOR ZERO	21
	8.2.	SENSOR SPAN	
	8.3.	CALIBRATION / CONFIGURATION KEYPAD	
	8.4.	MENU MODE SELECTION	
	8.4.1.	E: 1 – Sensor Zero	
	8.4.2.	E : 2 – Sensor Span	
	8.4.3.	E: 3 – Sensor Fsd	26
	8.4.4.	E: 4 - Output Zero (4mA)	
	8. <i>4</i> .5.	E:5- Output Span (20mA)	
	8.4.6. 8.4.7.	E:9 - Engineer diagnostics	
	• • • • • • • • • • • • • • • • • • • •	E: 77 – Sensor Firmware Version	
9.	CALI	BRATION	
	9.1.	SENSOR CALIBRATION	
	9.1.1. 9.1.2.	Sensor Zero Sensor Span	
	9.7.2.		
	9.2.	ANALOGUE OUTPUT CALIBRATION  Analogue Output Zero	
	9.2.1. 9.2.2.	Analogue Output Span	
10	. ROU	TINE GAS TESTING	32



STATUS

11.	SEN	ISOR REPLACEMENT	33
11	l.1.	Infrared sensor	33
12.	FUS	SES	39
13.	SPE	ECIFICATION	39
14.	DIM	ENSIONS	40
15.	CER	RTIFICATION	41

Installation, Commissioning & Routine Gas Testing
FGD10B Infrared Gas Detector



### 1. PACKAGE CONTENTS

The FGD10B is supplied in a box containing the following items:-

Description	Stock No
FGD10B Gas Detector Installation manual	*
Calibration certificate	

### Optional:-

Flow-through sampling adaptor	SS334
Sampling adaptor	SS336
Calibration / Configuration Keypad	SS748
Weather guard	SS841

<sup>\*</sup> Refer to <u>www.status-scientific.com</u> for Stock No's of the various gas types available.

### 2. SCOPE OF THE MANUAL

This manual relates specifically to the version of the FGD10B gas detector fitted with one of the following sensor types housed in a Type GSH4 sensor housing:-

An infrared sensor for the detection of Hydrocarbon (HC) gases.

or

An infrared sensor for the detection of Carbon dioxide.

Note – Infrared sensors are unsuitable for the detection of Hydrogen. However, this gas can be detected using a version of the FGD10B fitted either with pellistors or suitable electro-chemical sensors.

Installation, Commissioning & Routine Gas Testing FGD10B Infrared Gas Detector



### Description

The FGD10B is an explosion protected ATEX and IECEx certified fixed gas detector for use in potentially explosive atmospheres.

The infrared gas sensor is housed within a Type GSH4 certified flameproof housing, manufactured from stainless steel, attached to the main FGD10B enclosure.

The FGD10B enclosure is an aluminium die casting. Alternatively, a stainless steel (larger size) version of the enclosure is also available (suffix -SS).



The unit may be optionally fitted with a protective weather guard as shown in the following photograph.



Installation, Commissioning & Routine Gas Testing FGD10B Infrared Gas Detector



IMPORTANT – When used in hostile environments (e.g. oil platforms where the instrument is exposed to salt spray or diesel) it is recommended that the FGD10B is always fitted with its protective weather guard. The weather guard is attached with tamperproof screws to ensure that it is not inadvertently removed.

The unit comprises an instrument housing having two cable gland entries, one of which is normally fitted with a certified blank, and containing the connection terminals and electronics.

The housing containing the gas sensor has an M27 thread and is screwed into the bottom of the unit. The sensor housing itself is a certified component and must not be removed in service.

The main electrical features of the unit are:-

- Power supply 8 to 24 volts dc (non-intrinsically safe)
- Analogue output 4 to 20mA dc
- Gland entry threads available 20mm, ½" or ¾" NPT

#### 2.1. Gas types

Versions of the FGD10B Infrared are available for detection of gases, fitted with any of the following sensor types:-

- Infrared Hydrocarbon
- Infrared Carbon dioxide

Not suitable for the detection of hydrogen

Installation, Commissioning & Routine Gas Testing FGD10B Infrared Gas Detector



### 3. Installation

It is important that the correct cable and gland types are used when installing the FGD10B in a hazardous location.

The cable entry devices and blanking elements of unused apertures shall be of a certified flameproof type, suitable for the conditions of use and correctly installed.

With the use of conduit, a suitable certified sealing device such as a stopping box with compound shall be provided immediately at the entrance to the flameproof enclosure.

In order to prevent dangerous overloading of the FGD10B gas detector, it is fitted with an internal self resetting fuse which limits the maximum allowable power dissipation.

Guidance on the correct installation of systems is provided by EN60079-14: 2014. It is the responsibility of the installer to ensure compliance with the relevant standards.

To ensure effective gas detection, the FGD10B must be located at a height appropriate to the density of the target gas relative to air. For example, Methane (relative density 0.55) is lighter than air and so it will tend to accumulate at a high level within a confined space. Whereas Petroleum (relative density 2.8) is heavier than air and it will tend to accumulate at around ground level.

We recommend the user to make reference to European standard EN 60079-20-1:2019 which provides comprehensive gas flammability data (including relative density).

Installation, Commissioning & Routine Gas Testing
FGD10B Infrared Gas Detector



Cable entries

The cable entry threads are 20mm, ½" or ¾" NPT female.

The FGD10B enclosure is manufactured from die cast aluminium (stainless steel versions are also available). Therefore, the use of glands, conduit fittings and blanks made from brass should be avoided because if moisture is present, bi-metallic corrosion may occur due to the chemical reaction between the two materials.

Glands and fittings plated with nickel, tin or zinc will provide improved protection but in harsh environments the use of stainless steel is recommended.

When connecting the cores inside the unit it is beneficial to use pointed-nose pliers to carefully guide the cable cores from the cable entries at the rear of the enclosure towards the PCB mounted terminal connections situated near to the middle of the enclosure

### 3.1. Mounting and terminal access

The FGD10B should be mounted and secured using the mounting holes on the main unit

Figures 2 and 3 shows details of the FGD10B terminal connections – these can be accessed as follows:-.

- 1. Switch OFF the supply to the FGD10B.
- 2. Release the locking screw located near the lip of the enclosure cover by rotating clockwise.
- 3. Remove the enclosure front cover by rotating it several times in an anti-clockwise direction.
- The terminals can now be accessed.



Installation, Commissioning & Routine Gas Testing FGD10B Infrared Gas Detector



### FGD10B connections




Figure 2 – Armoured Cable Gland Installation




Figure 3 - EEx d Conduit Installation

Installation, Commissioning & Routine Gas Testing FGD10B Infrared Gas Detector



#### 3.2. Wiring details

#### 3.2.1. **FGD10B** Infrared

The infrared gas detector is powered from a 8 – 24 volt dc, 5W maximum output supply with a separate connection for the 4 – 20 mA output and as such requires 3 wires, see following diagram.

### Source





Fig 4a

### Sink



TD18/006 Page 14 Issue: 12 Change Note: 1904

Installation, Commissioning & Routine Gas Testing FGD10B Infrared Gas Detector



### 4. COMMISSIONING

Following completion of the installation:-

Ensure that the front cover has not been contaminated with dirt - paying particular attention to the thread. Replace the cover by rotating it several times clockwise until it reaches its limit then secure using the locking screw, turning in an anti-clockwise direction – do not over tighten.

## 4.1. Applying power

Once the installation is complete and the covers are secure then power can be applied. The power source should be between 12 and 24 volts dc.

# 5. RELATIVE RESPONSE CHARACTERISTICS

Unless otherwise specified, the FGD10B infrared hydrocarbon gas detector is calibrated to provide an output signal linearised for methane (CH<sub>4</sub>) during manufacture.

Note: the cross reference data was obtained using the lower explosive level for methane as 5% v/v.


However, the gas detector will also respond to a range of hydrocarbon gases. The characteristics shown in Figure 5 demonstrate the relative response to some of the common hydrocarbons.

If the expected target gas is other than methane then either:-

- a) The characteristics can be used as a guide when setting up the alarm levels in the associated control unit, e.g. where a general hydrocarbon response is required.
- b) The FGD10B can be fitted with a sensor that is characterised for different gases, contact Status Scientific Controls.







TD18/006 Page 16 Change Note: Issue: 12 1904

Installation, Commissioning & Routine Gas Testing FGD10B Infrared Gas Detector



Initial Gas Testing

FGD10B units are factory calibrated as detailed on the calibration certificate supplied with the instrument. However, it is always advisable after installation to confirm that the instrument reads zero with no gas present and responds accurately when presented with an appropriate concentration of the target gas.

The FGD10B sensor should be allowed to stabilise for the period specified on the associated calibration certificate before attempting to check the zero setting and gas response.

## 5.1. Zero gas

With no gas present check that the associated control panel display reads zero.


- If the instrument reads zero then no adjustment is required and gas response testing may now be carried out as described in Section 5.2.
- b) If the instrument does not read zero then adjustment of the zero setting is required as described in Section 6.1.1. Sensor Zero.
- c) If the analogue signal is connected to an associated control panel, confirm that when the FGD10B display reads zero, the control panel display also reads zero or, adjust as necessary in accordance with the control panel manufacturers' instructions.

<sup>\*</sup> Note – If there is the possibility of a background gas being present then zeroing of the detector should be carried out using a test gas cylinder of air in nitrogen.

Installation, Commissioning & Routine Gas Testing FGD10B Infrared Gas Detector



Figure 7 – Arrangement for Application of a Certified Test Gas



TD18/006 12 Change Note: Page 18 Issue: 1904

Installation, Commissioning & Routine Gas Testing FGD10B Infrared Gas Detector



### 5.2. Test gas

Figure 7 shows a typical arrangement for the application of a certified test gas.

The purpose of the test gas response check is to confirm that that the reading on the instrument corresponds with the test gas concentration.

- a) If the associated control panel reads correctly then no adjustment is required.
- b) If the above checks are satisfactory then the installation is now complete.
- c) If the instrument does not read correctly then adjustment of the sensor span setting is required as described in Section 6.1.2. - Sensor Span.

### 5.2.1. Gas connection points

Certified test gas can be applied either:-

a). directly to the FGD10B via the appropriate sampling/calibration adaptor.

or

b). remotely, by connecting a test gas sampling tube to the appropriate sampling/calibration adaptor and installing a test point at the remote end of the tube.

Method b) avoids the need to gain direct access to the unit in order to carry out routine gas testing. The sample tube should be taken to a convenient point and sited such that the risk of contamination is minimised. A means must be provided to 'cap off' the tube when not in use in order to prevent blockage.

The weather guard is provided with a 6mm O.D. push in tube connector to allow connection of a gas sampling tube. Firstly, remove the blanking plug by depressing the coloured plastic ring whilst pulling on the plug; now push in the gas sampling tube. The standard fitting is a push fit connector for 6mm O.D tubing. The connector is screwed into a 1/8" BSP thread; other fittings are available on request.

Where a weather guard is not fitted, the use of a sampling adaptor (Stock No. SS336) is required in order to present the gas to the FGD10B sensor.

Installation, Commissioning & Routine Gas Testing FGD10B Infrared Gas Detector



#### Sampling time 5.2.2.

Apply the test gas and allow a sufficient time for the sample to reach the gas detector. The response time will vary according to the length of the sampling tube.

#### 5.2.3. Suggested calibration gas levels.

### Hydrocarbon sensor:

Zero gas free air.

Span 2.5%v/v Methane.

### Carbon dioxide sensor

Zero Nitrogen.

Span 2.5%v/v CO2.

TD18/006 Page 20 Issue: 12 Change Note: 1904

Installation, Commissioning & Routine Gas Testing
FGD10B Infrared Gas Detector




### Calibration

Calibration of the sensor can be carried out by using the buttons on the circuit board as seen in Fig1 and Fig 2.

These buttons only work when the FGD10B Infrared has been powered for a minimum of 10 minutes.

### 5.3. Sensor Zero



Ensure the sensor is in a zero-gas environment. Note:

- Carbon Dioxide sensors cannot be zeroed in air due to the background levels of CO<sub>2</sub> present. These sensors are best zeroed whilst being exposed to 100% nitrogen.
- Where a purging gas has to be applied, use a flow rate of between 500 and 1000cc/min. Allow sufficient time for the sensor to respond.

Press the Zero button <a> Image: The Seconds to Zero the Sensor.</a> and hold for a minimum of 5 seconds to Zero the sensor.


Installation, Commissioning & Routine Gas Testing FGD10B Infrared Gas Detector



#### 5.4. **Sensor Span**

Always zero the sensor prior to performing a span operation.





Apply a known concentration of gas (applicable to sensor type) at a flow rate of between 500 and 1000cc/min. Allow time for the sensor to respond.

Press the Span button and hold for a minimum of 5 seconds to span the sensor.

Turn off and disconnect the calibration gas.

Note:

The calibration gas level must match with the level stored in the sensor. If the gas level is does not match then the keypad must be used to set the correct gas level.

TD18/006 Page 22 Issue: 12 Change Note: 1904

Installation, Commissioning & Routine Gas Testing
FGD10B Infrared Gas Detector



# 5.5. Calibration / Configuration Keypad

The FGD10B infrared sensor can be calibrated via a purpose designed keypad. The keypad allows the user to carry out the following:

- calibrate the sensor.
- 2) calibrate the 4 to 20 mA loop.
- 3) View the current gas level.
- 4) View the sensor raw data for diagnostic purposes.

Connect the keypad into the FGD10B as shown below:



The display will give the following messages:


SSCL	Company	
88:88	segment test	
SSCL	Manufacturer	
1.0.2	Firmware version	
CH4L, HC, CO2L, CO2P	gas type	
0.0	gas reading	

Note: if the display is continually showing - - - - then press both the zero and span buttons for at least 10 seconds. After which the keypad should go through the above sequence. This will allow the keypad to operate for 10 minutes.

Installation, Commissioning & Routine Gas Testing FGD10B Infrared Gas Detector



The menu system featured within the keypad calibration unit allows all calibration and configuration activities to be performed.



The keypad has the following functionality:

	Button	Function	Alternate Function
MENU	MENU	Open / Close Menu	Password
$\uparrow$	UP	Next / Increase	1
<b></b>	DOWN	Previous / Decrease	2
<b>←</b>	ENTER	Accept selection	3

This section of the manual discusses how the available menu options can be accessed, how the associated parameter may be changed via the selected menu option and what effect the change to the parameter has on the operation of the FGD10B Infrared gas detector.

### Note:

- It is important that that the FGD10B is correctly configured for the sensor in use, prior to performing any feature available in the menu system.
- 2) The menu system must not be selected when the keypad is removed.





### 5.6. Menu Mode Selection

The external Calibration / Configuration Keypad is used in its simplest form to calibrate the sensor for zero or gas drift.

It may also be used to configure the FGD10b.

The following features are available via the Calibration / Configuration Keypad menu system: -

Menu Option
E:1 – Sensor Zero
E: 2 – Sensor Span
E: 3 – Sensor Fsd
E: 4 – Output Zero (4mA)
E:5-Output Span (20mA)
E: 9 – Diagnostics
E: 77 – Sensor Firmware version

Several calibration modes exist in the FGD10B and these are accessible via the instruments simple menu system. To select a calibration mode follow this procedure:

- Press the MENU button, **E: 1** appears on the display.
- Press to select the calibration mode.
- To exit the menu press MENU.

While the instrument is in menu mode – any data displayed on the screen will alternate between the menu number and the reading.

Installation, Commissioning & Routine Gas Testing
FGD10B Infrared Gas Detector



### 5.6.1. E: 1 – Sensor Zero

Refer to section 6.1.1. for sensor calibration details.

### 5.6.2. E : 2 – Sensor Span

Refer to section 6.1.2. for sensor calibration details.

### 5.6.3. E: 3 - Sensor Fsd

This feature is a view-only feature. No configuration changes are possible from within this menu.

- From the menu system select menu option: E: 3 and press
   The sensor FSD will be displayed.
- Press MENU to close the menu system.

### 5.6.4. E: 4 – Output Zero (4mA)

Refer to section 6.2.1. for output calibration details.

### 5.6.5. E: 5 – Output Span (20mA)

Refer to section 6.2.2. for output calibration details.

### 5.6.6. E: 9 - Engineer diagnostics

This feature is a view-only feature. No configuration changes are possible from within this menu.

The information is for use of Status Scientific Controls personnel.

• From the menu system select menu option: **E: 9** and press



• Using the **1** button, display the required setting. The displayed values are as follows:

E: 90 Reading

E:92 Current sensor temperature °C E:93 Active sensor A to D counts E:94 Reference sensor A to D counts

E: 95 Fractional Absorbance

E: 96 Status flags

Installation, Commissioning & Routine Gas Testing FGD10B Infrared Gas Detector



#### 5.6.7. E: 77 - Sensor Firmware Version

This feature is a view-only feature. No configuration changes are possible from within this menu.

- From the menu system select menu option: E: 77 and press The sensor Firmware version will be displayed.
- Press MENU to close the menu system.

TD18/006 Change Note: Page 27 Issue: 12 1904

Installation, Commissioning & Routine Gas Testing FGD10B Infrared Gas Detector



#### **CALIBRATION** 6.

#### 6.1. Sensor Calibration



This feature allows the sensor to be calibrated. Ensure that the correct sensor type is selected in the configuration prior to calibration. Refer to section 5.6. for details of the menu system operation.

Note: if the password is in operation then the user will be prompted with PASS when ever the menu key is pressed. Pressing the MENU key again will result in the restricted user access, i.e. only the zero and span options will be available. Entering the correct password will give access to the full menu facility.

#### 6.1.1. Sensor Zero

- From the menu system select menu option: **E: 1** and press
- Ensure the sensor is in a zero-gas environment.
  - 1. Carbon Dioxide sensors cannot be zeroed in air due to the background levels of CO<sub>2</sub> present. These sensors are best zeroed whilst being exposed to 100% nitrogen.
  - 2. Where a purging gas has to be applied, use a flow rate of between 500 and 1000cc/min. Allow sufficient time for the sensor to respond.
- Press to zero the sensor, '---' will be displayed to confirm the sensor zero has been performed. Note:

exits the zero feature without Pressing MENU rather than performing the calibration.

Press MENU to close the menu system. Note:

The ZERO factor will be displayed momentarily on exit.

Installation, Commissioning & Routine Gas Testing FGD10B Infrared Gas Detector



#### 6.1.2. **Sensor Span**

Always zero the sensor prior to performing a span operation.

- From the menu system select menu option: E: 2 and press
- Apply a known concentration of gas (applicable to sensor type) at a flow rate of between 500 and 1000cc/min. Allow time for the sensor to respond.
- Using the **T** and **→** buttons, set the reading to that of the calibration gas level as %v/v.
- Press to span the sensor, '---' will be displayed to confirm the sensor span has been performed. Note: pressing MENU rather than ENTER exits the span feature without performing the calibration.
  - Wait until the reading is stable, if necessary press  $\longleftarrow$  again to span the sensor.
- Press MENU to close the menu system. Note: the SPAN factor will be displayed momentarily on exit.
- Turn off and disconnect the calibration gas.

Installation, Commissioning & Routine Gas Testing FGD10B Infrared Gas Detector




# 6.2. Analogue Output Calibration

The analogue output is that of a current source. In order to calibrate the output it is necessary to monitor the output signal. This can be performed in one of two ways:

#### **Current measurement:**

Connect an ammeter (or multimeter set to measure current in the mA range) in series with the analogue output.




Advantage: Direct measurement of output.

Disadvantage: The analogue output has to be disconnected to allow the

connection of the meter.

### Voltage measurement:

Permanently connect a 10R resistor in series with the analogue output. When calibration is required, connect a voltmeter (or multimeter set to measure voltage in the mV range) across the 10R resistor.



Advantage: No need to disturb wiring between FGD10B and control

unit

Disadvantage: Measurement accuracy dependent upon resistor tolerance.

Installation, Commissioning & Routine Gas Testing
FGD10B Infrared Gas Detector



### 6.2.1. Analogue Output Zero

- Monitor the current sourced from the analogue output of the FGD10B using a suitable method.
- From the menu system select menu option: **E: 4** and press
- Using the ↑ and ↓ buttons; adjust the output to the required level (4mA or 40mV).
- Press ← .
  Note:

Pressing MENU rather than exits the zero feature without performing the calibration.

Press MENU to close the menu system.
 Note:

The ZERO factor will be displayed momentarily on exit.

### 6.2.2. Analogue Output Span

Always zero the analogue output prior to performing a span operation.

- From the menu system select menu option: **E**: **5** and press (button 4).
- Using the and buttons; adjust the output to the required level.
- Press Note:

Pressing MENU rather than exits the span feature without performing the calibration.

Press MENU to close the menu system.
 Note:

The ANALOGUE OUTPUT SPAN factor will be displayed momentarily on exit.

Installation, Commissioning & Routine Gas Testing
FGD10B Infrared Gas Detector



### 7. ROUTINE GAS TESTING

Refer to Figure 7, which shows the arrangement for applying the test gas to the FGD10B.

- Before application of the test gas, check that the associated control panel reads zero with no known gas present in the atmosphere. If necessary, carry out adjustment of the zero setting as described in section Sensor Zero.
- Apply the test gas and allow a sufficient time for the sample to reach the gas detector. The response time will vary according to the length of the sampling tube.
- 3. Record the time taken for the gas detector to provide a reading of 90% (T<sub>90</sub>) of its final value (e.g. to reach 27% when using a 30% CH4 test gas). This reading should be retained for future reference as it can provide an indication of the health of the sinter (flame arrestor). This is situated in the base of sensor housing and it is through this device that the gas passes in order to reach the sensor itself. If necessary, carry out adjustment of the span setting as described in section 6.1.2. .

Carrying out the above procedure, and comparing the results with previous readings, will confirm that the FGD10B is functioning correctly, both physically and electrically.

In the unlikely event that the response time is seen to be increasing, when comparing periodic readings, it is advisable to change the unit so that it can be checked.

The period between carrying out routine gas testing shall be in accordance with the customer's specification.

Installation, Commissioning & Routine Gas Testing FGD10B Infrared Gas Detector




#### **SENSOR REPLACEMENT** 8.

#### 8.1. Infrared sensor

### Step1

Remove the grub screw in an anti-clockwise direction.




TD18/006 Page 33 12 Change Note: 1904 Issue:

Installation, Commissioning & Routine Gas Testing FGD10B Infrared Gas Detector



### Step 2

Turn sensor housing cover anti-clockwise to allow cover to open.




TD18/006 Page 34 12 Change Note: 1904 Issue:

Installation, Commissioning & Routine Gas Testing FGD10B Infrared Gas Detector



Step 3 Remove the sensor by pulling downwards




TD18/006 Change Note: Page 35 Issue: 12 1904

Installation, Commissioning & Routine Gas Testing FGD10B Infrared Gas Detector



Step 4 Carefully locate the pins in the sockets then push the new sensor upwards.




TD18/006 Page 36 Change Note: 1904 Issue:

Installation, Commissioning & Routine Gas Testing FGD10B Infrared Gas Detector



### Step 5

Replace the sensor housing by rotating in a clockwise direction untill fully




TD18/006 Page 37 Change Note: 1904 Issue:

Installation, Commissioning & Routine Gas Testing FGD10B Infrared Gas Detector



Step 6 Rotate the grub screw in a clockwise direction until fully tightened.



TD18/006 Page 38 Change Note: 1904 Issue:





#### **FUSES** 9.

A 340 mA 'Multifuse' is located within the FGD10B. It will automatically reset when normal conditions return.

#### **SPECIFICATION** 10.


Materials       Instrument Body – Aluminium Pressure Die Casting (Stainless Steel versions available, suffix –SS) Sensor Housing – Stainless Steel Grade 303 Weather guard – Stainless Steel Grade 304 & Nylon 66         Cable entries       : 2 x 20mm or 2 x ½NPT or 2 x ¾ NPT         Weights       : FGD10B (excluding weather guard) – 1.25Kg Weather guard – 200 grams         Infrared       : (Note – Infrared sensors have no response to Hydrogen)         Input voltage       : 8 to 24 volts dc         Input power       : 5 Watts maximum         Internal fuse       : 340mA surface mount 'Multifuse'         Bourns, MF-MSMF014-2       : Bourns, MF-MSMF014-2         Analogue output       : 4 to 20mA (10 bit resolution)         Comms output       : Communications with hand-held calibration keypad at 38400 baud (3V logic)         Hydrocarbon Sensor (Methane Calibration)       0 – 100% LEL (5% vol. CH <sub>4</sub> ) or 0 – 100% volume CH <sub>4</sub> Carbon Dioxide Sensor       Ranges from 0-1000ppm up to 0 – 100% volume CO <sub>2</sub> Response time       : Typically T <sub>90</sub> < 30 sec, depends upon sensor type         IP rating       : External via internal connector         Display / Keypad       : External via internal connector         Operating temperature       : - 20 to +60 ° C         Humidity range       : O to 95% RH non-condensing         Operating pressure       : Atmospheric + or - 10% <th></th> <th></th>		
Weights       : FGD10B (excluding weather guard) − 1.25Kg Weather guard − 200 grams         Infrared       : Infrared sensors have no response to Hydrogen)         Input voltage       : 8 to 24 volts dc         Input power       : 5 Watts maximum         Internal fuse       : 340mA surface mount 'Multifuse'         Bourns, MF-MSMF014-2       : 4 to 20mA (10 bit resolution)         Comms output       : Communications with hand-held calibration keypad at 38400 baud (3V logic)         Hydrocarbon Sensor (Methane Calibration)       0 − 100% LEL (5% vol. CH₄) or 0 − 100% volume CH₄         Carbon Dioxide Sensor       Ranges from 0-1000ppm up to 0 − 100% volume CO₂         Response time       : Typically T <sub>90</sub> < 30 sec, depends upon sensor type         IP rating       : Enclosure IP68, Sensor IP65         Display / Keypad       : External via internal connector         Operating temperature       : - 20 to +60 ° C         Humidity range       : 0 to 95% RH non-condensing         Operating       : Atmospheric + or - 10%		. (Stainless Steel versions available, suffix –SS) Sensor Housing – Stainless Steel Grade 303 Weather guard – Stainless Steel Grade 304 & Nylon 66
Weather guard – 200 grams  Infrared: (Note – Infrared sensors have no response to Hydrogen)  Input voltage: 8 to 24 volts dc  Input power: 5 Watts maximum  340mA surface mount 'Multifuse': Bourns, MF-MSMF014-2  Analogue output: 4 to 20mA (10 bit resolution)  Comms output: Communications with hand-held calibration keypad at 38400 baud (3V logic)  Hydrocarbon Sensor (Methane Calibration)  Measurement range: Carbon Dioxide Sensor  Ranges from 0-1000ppm up to 0 – 100% volume CH <sub>4</sub> : Carbon Dioxide Sensor  Ranges from 0-1000ppm up to 0 – 100% volume CO <sub>2</sub> Response time: Typically T <sub>90</sub> < 30 sec, depends upon sensor type  IP rating: Enclosure IP68, Sensor IP65  Display / Keypad  Operating: - 20 to +60 ° C  External via internal connector  Operating: - 20 to 95% RH non-condensing  Operating: Atmospheric + or - 10%	Cable entries	: 2 x 20mm or 2 x ½NPT or 2 x ¾ NPT
Input voltage : 8 to 24 volts dc  Input power : 5 Watts maximum  Internal fuse : 8 to 24 volts dc  Input power : 5 Watts maximum  340mA surface mount 'Multifuse' : Bourns, MF-MSMF014-2  Analogue output : 4 to 20mA (10 bit resolution)  Comms output : Communications with hand-held calibration keypad at 38400 baud (3V logic)  Hydrocarbon Sensor (Methane Calibration)  Measurement range : Carbon Dioxide Sensor  Ranges from 0-1000ppm up to 0 – 100% volume CH <sub>4</sub> : Carbon Dioxide Sensor  Ranges from 0-1000ppm up to 0 – 100% volume CO <sub>2</sub> Response time : Typically T <sub>90</sub> < 30 sec, depends upon sensor type  IP rating : Enclosure IP68, Sensor IP65  Display /  Keypad : External via internal connector  Coperating : - 20 to +60 ° C  Humidity range : 0 to 95% RH non-condensing  Operating : Atmospheric + or - 10%	Weights	
Input voltage : 8 to 24 volts dc Input power : 5 Watts maximum  Internal fuse : 340mA surface mount 'Multifuse' : Bourns, MF-MSMF014-2  Analogue output : 4 to 20mA (10 bit resolution)  Comms output : Communications with hand-held calibration keypad at 38400 baud (3V logic)  Hydrocarbon Sensor (Methane Calibration)  Measurement range : Typically T <sub>90</sub> < 30 sec, depends upon sensor type  IP rating : Enclosure IP68, Sensor IP65  Display /  Keypad : External via internal connector  Operating : O to 95% RH non-condensing  Operating : Atmospheric + or - 10%	Sensor type	Infrared
Input power  Internal fuse  340mA surface mount 'Multifuse'  Bourns, MF-MSMF014-2  Analogue output  Comms output  Comms output  Measurement range  Measurement range  Measurement range  I Typically T <sub>90</sub> < 30 sec, depends upon sensor type  IP rating  Display /  Keypad  Operating temperature  Humidity range  Sourns, MF-MSMF014-2  4 to 20mA (10 bit resolution)  Communications with hand-held calibration keypad at 38400 baud (3V logic)  Hydrocarbon Sensor (Methane Calibration)  0 - 100% LEL (5% vol. CH <sub>4</sub> ) or 0 - 100% volume CH <sub>4</sub> Carbon Dioxide Sensor  Ranges from 0-1000ppm up to 0 - 100% volume CO <sub>2</sub> External via internal connector  External via internal connector  1 - 20 to +60 ° C  2 - 20 to +60 ° C  34 to 20mA (10 bit resolution)  1 - 20 to +60 ° C  2 - 20 to +60 ° C  2 - 20 to +60 ° C  3 - 20 to 95% RH non-condensing  Operating  3 - 4 to 20mA (10 bit resolution)  2 - 100m Lel (5% vol. CH <sub>4</sub> ) or 0 - 100% volume CH <sub>4</sub> 3 - 100m CH <sub>4</sub> 3 - 100m CH <sub>4</sub> 3 - 100m CH <sub>4</sub> 4 to 20mA (10 bit resolution)  4 to 20mA (10 bit resolution)  6 - 100m CH <sub>4</sub> 7 - 100m CH <sub>4</sub> 8 - 100m CH <sub>4</sub> 9 - 100m CH <sub>4</sub> 1 - 100m CH <sub>4</sub> 2 - 100m CH <sub>4</sub> 2 - 100m CH <sub>4</sub> 3 - 100m CH <sub>4</sub> 1 - 100m CH <sub>4</sub> 2 - 100m CH <sub>4</sub> 2 - 100m CH <sub>4</sub> 3 - 100m CH <sub>4</sub> 2 - 100m CH <sub>4</sub> 3 - 100m CH <sub>4</sub> 2 - 100m CH <sub>4</sub> 3 - 100m CH <sub>4</sub> 2 - 100m CH <sub>4</sub> 3 - 100m CH <sub>4</sub> 2 - 100m CH <sub>4</sub> 3 - 100m CH <sub>4</sub> 2 - 100m CH <sub>4</sub> 3 - 100m CH <sub>4</sub> 3 - 100m CH <sub>4</sub> 4 - 100m CH <sub>4</sub> 5 - 100m CH <sub>4</sub> 6 - 100m C		(Note – Infrared sensors have no response to Hydrogen)
Internal fuse  340mA surface mount 'Multifuse' Bourns, MF-MSMF014-2  Analogue output  Comms output  Communications with hand-held calibration keypad at 38400 baud (3V logic)  Hydrocarbon Sensor (Methane Calibration)  0 - 100% LEL (5% vol. CH <sub>4</sub> ) or 0 - 100% volume CH <sub>4</sub> Carbon Dioxide Sensor  Ranges from 0-1000ppm up to 0 - 100% volume CO <sub>2</sub> Response time  Typically T <sub>90</sub> < 30 sec, depends upon sensor type  IP rating  Enclosure IP68, Sensor IP65  Display /  Keypad  Operating  temperature  Humidity range  Coperating  Atmospheric + or - 10%	Input voltage	: 8 to 24 volts dc
Internal fuse  Bourns, MF-MSMF014-2  Analogue output  Comms output  Comms output  Comms output  Comms output  Comms output  Comms output  Measurement range  Measurement range  Carbon Dioxide Sensor  Ranges from 0-1000ppm up to 0 – 100% volume CH <sub>4</sub> Carbon Dioxide Sensor  Ranges from 0-1000ppm up to 0 – 100% volume CO <sub>2</sub> Response time  Typically T <sub>90</sub> < 30 sec, depends upon sensor type  IP rating  Enclosure IP68, Sensor IP65  Display /  Keypad  Coperating  Coperating  Coperating  Coperating  Atmospheric + or - 10%  Communications with hand-held calibration keypad at 384 to 20mA (10 bit resolution)  Coperating  Coperating  Atmospheric + or - 10%	Input power	: 5 Watts maximum
Analogue output : 4 to 20mA (10 bit resolution)  Comms output : Communications with hand-held calibration keypad at 38400 baud (3V logic)  Hydrocarbon Sensor (Methane Calibration)  Measurement range : 0 - 100% LEL (5% vol. CH <sub>4</sub> ) or 0 - 100% volume CH <sub>4</sub> Carbon Dioxide Sensor  Ranges from 0-1000ppm up to 0 - 100% volume CO <sub>2</sub> Response time : Typically T <sub>90</sub> < 30 sec, depends upon sensor type  IP rating : Enclosure IP68, Sensor IP65  Display /  Keypad : External via internal connector  Certaing : - 20 to +60 ° C  temperature	Internal fuse	340mA surface mount 'Multifuse'
Comms output  Comms output  Comms output  Comms output  Communications with hand-held calibration keypad at 38400 baud (3V logic)  Hydrocarbon Sensor (Methane Calibration)  0 - 100% LEL (5% vol. CH <sub>4</sub> ) or 0 - 100% volume CH <sub>4</sub> Carbon Dioxide Sensor  Ranges from 0-1000ppm up to 0 - 100% volume CO <sub>2</sub> Response time  Typically T <sub>90</sub> < 30 sec, depends upon sensor type  IP rating  Enclosure IP68, Sensor IP65  Display /  Keypad  Coperating  1 - 20 to +60 ° C  External via internal connector  External via internal connector  Coperating  2 - 20 to 95% RH non-condensing  Coperating  3 - 4 to 20mA (10 bit resolution)  1 - 100 bit resolution  1 - 100 bit resolution)  1 - 100 bit resolution  2 - 100 bit resolution  3 - 100 bit resolution  4 - 100 bit resolution  1 - 100 bit resolution  2 - 100 bit resolution  2 - 100 bit resolution  3 - 100 bit resolution  4 - 100 bit resolution  4 - 100 bit resolution  5 - 100 bit resolution  1 - 100 bit resolution  2 - 100 bit resolution  2 - 100 bit resolution  3 - 100 bit resolution  4 - 100 bit resolution  4 - 100 bit resolution  5 - 100 bit resolution  6 - 100 bit resolution  9 - 100 bit resolution  1 - 100 bit resolution		Bourns, MF-MSMF014-2
38400 baud (3V logic)  Hydrocarbon Sensor (Methane Calibration)  0 - 100% LEL (5% vol. CH <sub>4</sub> ) or 0 - 100% volume CH <sub>4</sub> Carbon Dioxide Sensor  Ranges from 0-1000ppm up to 0 - 100% volume CO <sub>2</sub> Response time : Typically T <sub>90</sub> < 30 sec, depends upon sensor type  IP rating : Enclosure IP68, Sensor IP65  Display /  Keypad : External via internal connector  Keypad : - 20 to +60 ° C  temperature	•	: 4 to 20mA (10 bit resolution)
Measurement range       : 0 - 100% LEL (5% vol. CH <sub>4</sub> ) or 0 - 100% volume CH <sub>4</sub> Carbon Dioxide Sensor       Ranges from 0-1000ppm up to 0 - 100% volume CO <sub>2</sub> Response time       : Typically T <sub>90</sub> < 30 sec, depends upon sensor type         IP rating       : Enclosure IP68, Sensor IP65         Display / Keypad       : External via internal connector         Operating temperature       : - 20 to +60 ° C         Humidity range       : 0 to 95% RH non-condensing         Operating       : Atmospheric + or - 10%	Comms output	
Response time : Typically T <sub>90</sub> < 30 sec, depends upon sensor type  IP rating : Enclosure IP68, Sensor IP65  Display /  Keypad : External via internal connector  Coperating : - 20 to +60 ° C  temperature		Hydrocarbon Sensor (Methane Calibration)
range Carbon Dioxide Sensor Ranges from 0-1000ppm up to $0-100\%$ volume $CO_2$ Response time : Typically $T_{90} < 30$ sec, depends upon sensor type  IP rating : Enclosure IP68, Sensor IP65  Display / Keypad : External via internal connector  Operating temperature : - 20 to +60 $^{\circ}$ C  Humidity range : 0 to 95% RH non-condensing  Operating : Atmospheric + or - 10%		0 – 100% LEL (5% vol. CH <sub>4</sub> ) or 0 – 100% volume CH <sub>4</sub>
Response time : Typically T <sub>90</sub> < 30 sec, depends upon sensor type  IP rating : Enclosure IP68, Sensor IP65  Display /  Keypad : External via internal connector  Coperating : - 20 to +60 ° C  temperature		Carbon Dioxide Sensor
IP rating : Enclosure IP68, Sensor IP65  Display / Keypad : External via internal connector  Operating : - 20 to +60 ° C temperature  Humidity range : 0 to 95% RH non-condensing  Operating : Atmospheric + or - 10%		Ranges from 0-1000ppm up to 0 – 100% volume CO <sub>2</sub>
Display /  Keypad  Operating temperature  Humidity range  Coperating The state of t	Response time	: Typically T <sub>90</sub> < 30 sec, depends upon sensor type
External via internal connector  Coperating temperature  Humidity range : 0 to 95% RH non-condensing  Operating : Atmospheric + or - 10%	IP rating	: Enclosure IP68, Sensor IP65
Coperating : - 20 to +60 ° C temperature  Humidity range : 0 to 95% RH non-condensing  Operating : Atmospheric + or - 10%	Display /	External via internal connector
temperature Humidity range : 0 to 95% RH non-condensing  Operating : Atmospheric + or - 10%	Keypad	. External via internal connector
Humidity range : 0 to 95% RH non-condensing  Operating : Atmospheric + or - 10%		: - 20 to +60 ° C
. Authospholic 1 of 1070		: 0 to 95% RH non-condensing
		: Atmospheric + or - 10%

TD18/006 Page 39 12 Change Note: Issue: 1904

Installation, Commissioning & Routine Gas Testing FGD10B Infrared Gas Detector



#### 11. **DIMENSIONS**



Maximum Depth = 127mm

TD18/006 Page 40 12 Change Note: 1904 Issue:

Installation, Commissioning & Routine Gas Testing FGD10B Infrared Gas Detector



#### CERTIFICATION 12.

The FGD10 Series of Gas Detectors are ATEX and IECEx certified for use in potentially explosive atmospheres and is marked as follows:-

WARNING - DO NOT OPEN WHEN AN EXPLOSIVE GAS ATMOSPHERE IS PRESENT **GAS DETECTOR TYPE FGD10 \*\*** STATUS SCIENTIFIC IECEx SIR 08.0009X CONTROLS LTD. T4 (Ta -20°C to +60°C) MANSFIELD NG18 5ER.UK. **( (** 1180 II 2 G Ex d IIC SIRA 08ATEX1031X SERIAL No. XXXXXX CIRCUIT RATING: 24VDC, 5W RELAY CONTACT RATING: 300VAC. 3A MAX.

\*\* Denotes additional characters that define the gas detector configuration e.g. Enclosure type and sensor arrangement.

YYYY - Denotes year of manufacture.

### Special Conditions of Safe Use

There are no special conditions of safe use applicable to the version of the FGD10 covered by this user manual.

Compliance with the Essential Health and Safety Requirements has been assured by compliance with:

> EN 60079-0: 2018 EN 60079-1: 2014

#### Electrical data

Power supply - 8Vdc to 24Vdc, 5W

### Installation instructions

Installation, Commissioning & Routine Gas Testing FGD10B Infrared Gas Detector



The cable entry devices and blanking elements of unused apertures shall be of a certified flameproof type, suitable for the conditions of use and correctly installed.

With the use of conduit, a suitable certified sealing device such as a stopping box with compound shall be provided immediately at the entrance to the flameproof enclosure.

A copy of the certificate is available for download from:-

www.status-scientific.com

TD18/006 Page 42 Issue: 12 Change Note: 1904

Installation, Commissioning & Routine Gas Testing FGD10B Infrared Gas Detector



### **CUSTOMER NOTES**

Change Note: TD18/006 Page 43 12 1904 Issue: