

DATA SHEET

CO₂ Sensors

Robust Range—ExplorIR[®]-M



FEATURES

- Low power / energy consumption—3.5mW
- Measures up to 100% CO₂ concentration
- Miniature format; vibration and shock resistant
- Solid-state; no moving parts, no heated filaments
- Digital (UART) output
- > 15 years lifetime



Supply Voltage



Power Consumption



Operating Temp



Output Digital



Response Time



BENEFITS

- Reliable in harsh, volatile environments
- Ideal for low power and battery applications
- Up to 50X lower power than typical NDIR CO₂ sensors
- Low maintenance
- Suitable for wireless, portable, wearable and self-powered systems



CO₂ MEASUREMENT SPECIFICATIONS

Sensing method	Non-dispersive infrared (NDIR) absorption
Sample method	Diffusion
Measurement range	0—5%, 0—20%, 0—100%
Accuracy ^d	± (70ppm+5% of reading) (100% range ± (300ppm+5% of reading ^b))
Pressure dependence ^e	0.15% of reading per mbar in normal atmospheric conditions
Operating pressure range ^f	500mbar to 2bar
Response time, T90 ^g	10sec—2mins (configurable via filter and application)+ Reading refreshed twice per sec.



TECHNICAL SPECIFICATIONS

Supply voltage	3.25—5.5V _{DC} (3.3V recommended)
Current ^a	Peak Current 33mA Average Current <1.5mA
Power consumption ^a	3.5mW
Output type	3.3V TTL level UART
Temperature	
Operating:	0°C to +50°C (standard) -25°C to +55°C (extended)
Storage:	-30°C to +70°C
Humidity ^b	0—95% Rh, non-condensing
Start-up time ^c	1.2s
Connector	4 x 0.5mm sq pins

Need help? Ask the expert
Tel: + 44 (0)1236 459 020
and ask for “Technical”





NOTES

- Power measurements for standard CO₂ sensor with 2 readings per second. Temperature and RH% measurements increase power consumption.
- For extended operation in high temperature and humidity environments, contact SST.
- Time to a valid reading is determined by digital filter setting; typically 4-8 seconds.
- All measurements are at NTP unless otherwise stated.
- Calibrated for 1013mbar. SST can supply advanced pressure correction advice when operating outside normal atmospheric conditions.
- External pressure calibration required.
- Response time to a step change in gas level is dependent on application/filter/flow rate/diffusion.



OUTLINE DRAWING & ELECTRICAL CONNECTIONS

Pin	Designation
0V	GND
V+	3.3V to 5V
Tx OUT	UART Tx from sensor $V_{oh} = 3V$
Rx IN	UART Rx to sensor used for configuration



0.5mm SQUARE PINS



ORDER INFORMATION

Generate your specific part number using the convention shown opposite. Use only the numbers that correspond to the sensor option you require — omit those you do not.

E X P L O R I R - M - XXX - X - XXX

Measurement Range	Extended Temperature	Evaluation Kit
5 0-5%	Blank Without Extended Temperature	KIT*
20 0-20%	E With Extended Temperature	
60 0-60%		
100 0-100%		

NOTE: *Kit includes USB & Evaluation Software

CAUTION

Do not exceed maximum ratings and ensure sensor(s) are operated in accordance with their requirements. Carefully follow all wiring instructions. Incorrect wiring can cause permanent damage to the device. Do NOT use chemical cleaning agents.

Failure to comply with these instructions may result in product damage.

INFORMATION

As customer applications are outside of SST Sensing Ltd.'s control, the information provided is given without legal responsibility. Customers should test under their own conditions to ensure that the equipment is suitable for their intended application.

For technical assistance or advice, please email:
technical@sstsensing.com

General Note: SST Sensing Ltd. reserves the right to make changes to product specifications without notice or liability. All information is subject to SST Sensing Ltd.'s own data and considered accurate at time of going to print.